

Assembly Guide Enclosure

If you do not need to attach an antenna, just follow steps 1,4 and 6.

Step 1 - Place the top-case on a soft surface



Step 2 (optional)- If you have a Wandboard with Wi-Fi capabilities (Wandboard DUAL). **You will need to open the antenna opening**

Before



After



Step 3 (optional)- **Connect the Wi-Fi cable:** plug the cable in the μ FL IPEX connector and lead it through the open hole to the other side



hole for
antenna
cable




Step 4 - Insert your Wandboard (remember to insert SD-card with OS in the module first)



Step 5 (optional) - Make sure the bolt has the correct orientation, and then fasten it (the rings should be on the outside of the case)



Step 6 - Insert and fasten the bottom-enclosure with the screws and attach the rubber feet.



Step 7 (optional) - Attach the antenna.

